

ZZZ 213

Trim kit installation instructions

1

Contents of the kit will consist of four white trim-groove filler pieces, four "F" channels, and Instructions.

**2**

Remove skylight from box and position so that finish groove is facing up. Use packing materials under skylight to prevent scratching of exterior cladding during installation of the trim kit filler pieces.

**3**

Cut the top and bottom filler pieces to fit in between the metal sides of the deck seal. Next, cut the side filler pieces to fit between the top and bottom filler pieces.

**4**

Use 4d, 1 1/2" finish nails (not included) to secure the filler pieces to the skylight. Keep nails at least 2" from ends of filler pieces. Set the nails and cover with white painters caulk.

**5**

Prepare the rough opening. Any drywall or other finish material that is above the plane of the roof deck must be cut even with the top of the roof deck or just below the roof deck.

**6**

Starting with the sides, cut the "F" channel to size. Some angled cuts may be required for flared light wells.
NOTE: Unfinished skylight shown for contrast.



ZZZ 213

Trim kit installation instructions

7

Place the long flexible leg of the "F" channel over the finish material. The short leg can go behind the finish material. The "F" channel will cover over material within 1¼" of the top of the roof deck. Finish material that is more than 1¼" below the roof deck will not be covered by the "F" channel. *Note: Areas that are prone to severe cold weather conditions should fill in any gaps around the rough opening with insulation as necessary.*



8

If needed, score along the base of the short leg and peel off. Make sure long leg of the "F" channel has a tight fit to the finish material.



9

Keep the top flange of the "F" channel on the same plane as the roof deck. This will ensure a tight fit to the bottom of the skylight. After the "F" channel is fitted over the finish material, nail the top flange to the roof deck (2-3 nails per side). Repeat this step for the top and bottom "F" channels. *Note: The small upturned lip of the "F" channel must be slightly above the plane of the roof deck – approximately 1/8".*



10

Once the "F" channels are nailed down, find the midway point for all four sides and place a mark that can be seen once the skylight is in place. Follow this same procedure on the four exterior sides of the skylight. Use these marks to center the skylight prior to securing to the roof deck. At this point, follow installation instructions included with skylight.

